
SKIP*HOP

90182410-01

6 m+

expandable enclosure




OWNER'S MANUAL


Read and follow all instructions and warnings before assembly and use of Playview Expandable Enclosure.

IMPORTANT! Read and follow these instructions carefully and keep for future reference.


CONTENTS:




Panels (x4)




Wall Mount Templates (x2)



Door-Adjacent Panel




Door Panel



Wall Mounts (x4) (Requires screws/ anchors)

SETUP:

Adult assembly required.




For easy storage and shipping, Panels come assembled in sets of 2.



1. To detach Panels, unlock screws on all Panels by turning counter-clockwise.



2. Pull up on the Panel containing the screw, and down on the other Panel.



3. To assemble Panels together, line up the posts on the top and bottom and press together. The bottom tabs will click in.



Be sure Panels are folded in the proper direction. Hinges may disengage if too much force is put on them in the wrong direction, causing the panels to separate.





4. Place Panels in desired configuration to ensure fit. Lock together by turning screws down clockwise until you hear a click.

IMPORTANT: See Configurations section before locking Panels.


CONFIGURATIONS:

Modular steel-frame panels create over 20 square feet/1.86 square meters of playspace!






Keep away from landings or changes in floor elevation. Not for outdoor use. Not intended for animals. Do NOT use if mesh Panel is ripped.



DOOR ASSEMBLY/USE:

Adult assembly required.




Be sure to assemble the Door Panel and Door-Adjacent Panel next to each other so that the latch lines up with the post.



To open door latch, squeeze both buttons together and pull up on entire door to release.

Center indicator on latch will be red when the door is unlocked.




To close the door latch, lift door onto bottom post. Lift the latch while squeezing buttons on both sides. Place down over top post and release buttons.

USING WALL MOUNTS:


Adult assembly required.

1. Set up Panels in desired location to ensure fit.


2. If you have a baseboard or uneven surface, we suggest attaching a filler board to walls to create a flat, even surface. The board should run the entire height from the baseboard to the top of the enclosure to prevent any unsafe gaps.



3. Place template A against the wall/surface, and level template before marking holes on top and bottom.




4. Attach upper and lower Wall Mounts marked "A" to Panel.




5. Select screws/anchors appropriate for the material you are mounting to, with a strength of 50lbs or more. Do not use drywall screws or any screw with a flat top and tapered head, as these can damage the Wall Mounts.


6. Screw into wall.




7. On other side, place Template B on wall and mark holes. Screw the Wall Mounts marked "B" directly into the wall.



8. Attach the Panel to the Wall Mounts.



9. Attach the rest of the Panels.



10. Lock screws on all Panels.

DISASSEMBLY INSTRUCTIONS:




To disassemble, unlock all of the Panel screws.



Pinch tabs on bottom thread while pulling up on Panel to release.



Separate all Panels by pulling up on the Panel containing the screw, while pushing down on the other Panel.



We recommend storing the panels together in pairs.
*Always store the Door Panel with Door Adjacent Panel.

Store in a dry, cool place.

CLEANING AND CARE:

IMPORTANT: Periodically check the Expandable Enclosure for signs of damage, wear or missing components. Do not use if any part is missing, worn or damaged. Check regularly to ensure all hardware and mountings are tightened.

FABRIC: Spot clean only.

PLASTIC CORNERS: Wipe with a damp cloth.

⚠WARNING:

- Install according to manufacturer's instructions. Keep these instructions for future use.
- Intended for use with children from 6 months through 24 months, up to 35 inches.
- This product will not necessarily prevent all accidents. **NEVER LEAVE CHILD UNATTENDED!**
- **Children have died or been seriously injured when enclosures are not securely installed.**
- ALWAYS install and use enclosures as directed using all required parts.
- STOP using when a child can climb over or dislodge/open the enclosure.
- Use only with the locking/latching mechanism securely engaged.
- Never use to keep child away from pool.
- To prevent falls, never use at top of stairs.
- DO NOT use as a barrier to block doorways, stairs or hazards such as fireplaces, heaters, stoves, ovens or other dangerous areas.
- Always keep child in view while in product.
- To avoid tip over, place product on a flat, level surface. Do not use on uneven surfaces.
- Do not use this product if your child can lift or push the enclosure to an unsafe area.
- This expandable enclosure or its individual panels must not be fitted across windows.
- Do not leave anything in the play enclosure which may provide a foothold or create a danger of suffocation or strangulation.
- Child can become entrapped and die when improvised netting or covers are placed on top of the product. Never add such items to confine child in product.
- Strings can cause strangulation! DO NOT place items with a string around child's neck, such as hood strings or pacifier cords. DO NOT suspend strings over product or attach strings to toys.
- Be aware of the danger of allowing other children to play near the product.
- Check product before assembly and periodically during use. Do not use this product if it is damaged, broken or disassembled. Throw away at first sign of damage or weakness.
- Only replacement parts supplied by the manufacturer should be used on the product.
- To prevent serious injury or death, securely install expandable enclosure and use according to manufacturer's instructions.
- This expandable enclosure is intended for indoor use and is not to be exposed to outdoor elements.
- Remove and discard all packaging materials properly before use.

© Skip Hop, Inc.
100 W 33 ST, STE 1125, NY, NY 10001
In the US: 888.782.9548
US warranty: www.skiphop.com

Meets or exceeds applicable safety standards.