SKIP*HOP

186025.04


STROLL & GO™

portable baby soother

CLEANING AND CARE:

Clean with dry cloth only.

INSTRUCTIONS FOR USE:



IMPORTANT! Keep for future reference.

Read all instructions and warnings carefully before use of the portable baby soother.

⚠WARNING: ALWAYS use with adult supervision. DO NOT leave baby unattended with product. NEVER place product in crib. Product is not intended for use in cribs. NEVER use this product in a motor vehicle. Do not allow this item or any other product to interfere with proper functioning of carrier or stroller restraint system. Only use with baby seated with harness straps in place. Remove and discard all packaging material prior to use.

Battery Information:
Install/replace batteries (by adult only): Requires 3 AAA batteries.
1. Open battery cover with screwdriver.
2. Insert or replace with 3 AAA 1.5V batteries. Be sure to insert with the correct polarity.
3. Replace cover and secure screws with screwdriver.

At the end of the product life, remove batteries from product by following the above battery replacement instructions. Always dispose of used batteries properly. See section on safety and disposal information. To prolong the life of this product remove batteries when toy is in storage.
- Batteries are to be inserted with the correct polarity.
- Do not burn batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before being charged.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Different types of batteries or new and used batteries are not to be mixed.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.

CONSUMER INFORMATION: SAFETY AND DISPOSAL
At end of product life remove batteries from product by following the battery replacement instructions.

Substances used in batteries pose potential environmental and health effects. Do not mix waste batteries with other waste. Keep waste batteries separate. Do not dispose of by landfill or by incineration. Return waste batteries to your point of purchase or recycle center. Recycle all waste batteries per local regulation.

Do not dispose of Waste Electrical Electronic Equipment (WEEE) in unsorted municipal waste; collect separately. Dispose of at WEEE collection sites per local regulation. WEEE contains chemicals that are hazardous to the environment and human health. The end-user's participation is critical to the success of WEEE collection.

CAN ICES-3(B)/NMB-3(B)

⚠CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

⚠WARNING: NEVER use this product in a motor vehicle. Death or serious injury can occur from your child's contact with hard objects during a crash.